
Coolant Fan (two speeds),

from September 1998

Deviate relay location and fuseplacements as well as the locations of multiple connectors see section "component locations".



Fuse colors

30 A - green

25 A - white

20 A - yellow

15 A - blue

10 A - red


7,5 A - brown

5 A - beige

3 A - violet

Edition 08/99





ws = white sw = black ro = red br = brown gn = green

bl = blue gr = grey li = lilac

li = lilac ge = yellow

A - Battery

F18 - Coolant Fan Control (FC) Thermal Switch S180 - Fuse -8- (30) in fuse bracket/battery

T3 - 3-Pin Connector

T3a - 3-Pin Connector, in engine compartment, left

front

V7 - Coolant Fan

12

- Ground connection, in engine compartment, left