
Power outlet (12V),

from September 1998

Deviate relay location and fuseplacements as well as the locations of multiple connectors see section "component locations".



Fuse colors

30 A - green

25 A - white

20 A - yellow

15 A - blue

10 A - red


7,5 A - brown

5 A - beige

3 A - violet

Edition 12/98





ws = white sw = black ro = red br = brown gn = green bl = blue gr = grey li = lilac

ge = yellow

D - Ignition/Starter SwitchS235 - Fuse 35 in fuse holderT3 - 3-Pin Connector

U5 - 12 V-Socket, in luggage compartment, right

60) - Ground connection, in luggage compartment, left

- Ground connection -1-, in rear wiring harness

Threaded connection -2- (30) on the relay plate

Plus connection (30), in instrument panel wiring harness

- Plus connector -4- (30), in instrument panel wiring harness