



# ETKA GKB-Übersicht

|        |      |    |    |           |           |        |       |            |
|--------|------|----|----|-----------|-----------|--------|-------|------------|
| Modell | Jahr | HG | UG | Bildtafel | Fgst.-Nr. | Update |       |            |
| OCT    | 00   | 1  | 99 | 199-20    |           | 64     | 20:51 | 17.04.2004 |

| GKB  | Bauart | Einbauzeit  | Ltr | kW  | PS  | Zyl | Bemerkung |
|------|--------|-------------|-----|-----|-----|-----|-----------|
| ---- | -----  | -----       | --- | --- | --- | --- | -----     |
| CZL  | 5S     | 10/96       | 1,9 | 66  | 90  | 4   |           |
| CZM  | 5S     | 10/96-04/99 | 1,8 | 92  | 125 | 4   |           |
| DBZ  | 5S     | 05/98-07/98 | 1,8 | 110 | 150 | 4   |           |
| DEA  | 5S     | 05/98-07/98 | 1,9 | 81  | 110 | 4   |           |
| DEA  | 5S     | 08/97       | 1,9 | 81  | 110 | 4   |           |
| DLP  | 5S     | 05/98-07/98 | 1,6 | 74  | 100 | 4   |           |
| DMN  | 4A     | 06/97-04/99 | 1,8 | 92  | 125 | 4   |           |
| DMT  | 4A     | 08/97       | 1,9 | 81  | 110 | 4   |           |
| DQY  | 5S     | 05/98-07/98 | 1,9 | 66  | 90  | 4   |           |
| DRY  | 5S     | 10/96-07/98 | 1,6 | 55  | 75  | 4   |           |
| DRY  | 5S     | 10/96       | 1,6 | 55  | 75  | 4   |           |
| DRZ  | 5S     | 05/97       | 1,9 | 50  | 68  | 4   |           |
| DSD  | 4A     | 03/98-04/99 | 1,8 | 92  | 125 | 4   |           |
| DTQ  | 5S     | 02/99       | 1,4 | 44  | 60  | 4   |           |
| DUS  | 5S     | 08/98       | 1,9 | 50  | 68  | 4   |           |
| DUT  | 5S     | 08/98       | 1,6 | 55  | 75  | 4   |           |
| DUU  | 5S     | 02/97-12/97 | 1,6 | 74  | 100 | 4   |           |
| DUU  | 5S     | 08/98       | 1,6 | 74  | 100 | 4   |           |
| EBD  | 5S     | 08/98-04/99 | 1,8 | 92  | 125 | 4   |           |
| EBE  | 5S     | 01/99       | 1,8 | 110 | 150 | 4   |           |
| EBF  | 5S     | 08/98       | 1,9 | 81  | 110 | 4   |           |
| EBJ  | 5S     | 08/98       | 1,9 | 66  | 90  | 4   |           |
| ECP  | 4A     | 08/98       | 1,8 | 110 | 150 | 4   |           |
| ECS  | 4A     | 08/98-04/99 | 1,8 | 92  | 125 | 4   |           |
| ECS  | 4A     | 08/98       | 1,8 | 92  | 125 | 4   |           |
| ECT  | 4A     | 08/98       | 1,6 | 74  | 100 | 4   |           |
| ECW  | 5S     | 08/98       | 1,8 | 110 | 150 | 4   |           |
| ELZ  | 4A     | 05/99       | 2,0 | 85  | 115 | 4   |           |
| EMR  | 5S     | 05/99       | 2,0 | 85  | 115 | 4   |           |
| ERQ  | 4A     | 02/97-12/97 | 1,6 | 74  | 100 | 4   |           |
| ERQ  | 4A     | 08/98       | 1,6 | 74  | 100 | 4   |           |
| ERW  | 5S     | 11/99       | 2,0 | 88  | 120 | 4   |           |
| EVS  | 5S     | 01/00-07/00 | 1,8 | 110 | 150 | 4   |           |
| GOG  | 5S     | 10/99       | 1,9 | 66  | 90  | 4   |           |
| GOG  | 5S     | 11/99       | 2,0 | 85  | 115 | 4   |           |