# 

## **Technical data**

#### Engine number

The engine number ("Engine code number" and "serial number") is on the left rear of the cylinder block.

Additionally, there is a sticker on the toothed belt guard with "Engine code" and "Serial number".

The engine code is also included on the vehicle data sticker.

#### Note:

Furthermore, the engine code is stamped onto the front engine lifting eye (visible after removal of engine cover).

### Engine data

Code letters		AWM
Production		04.2000 >
Capacity	ltrs.	1.781
Output	kW at rpm	125/5900
Torque	Nm at rpm	225/1950 - 5000
Bore	diameter mm	81.0
Stroke	mm	86.4
Compression		9.3
RON		95 <sup>1)</sup>
Injection-/Ignition system		Bosch Motronic
Knock control		yes
On Board Diagnositc (OBD)		yes
Oxygen sensor control		yes
Catalytic converter		yes
Charging		yes

<sup>1)</sup> Regular unleaded petrol RON 91 can be used but will cause a slight loss of power.

Code letters	AWM
Exhaust gas recirculation system	no
Intake manifold changeover	
Camshaft timing control	
Secondary air inlet	yes
Valve timing	
with 1 mm valve lift and 0 mm valve clearance	
Inlet opens after TDC	18°
Inlet closes after BDC	28°
Exhaust opens before BDC	28°
Exhaust closes before TDC	8 °