



## Spoiler, removing and installing

### 1 - Bumper

- ◆ Remove before detaching spoiler

### 2 - Spoiler

- To remove, take out expanding clips -3- on both sides.
- Unclip retaining tabs (arrow) from spoiler and remove spoiler from bumper.

### 3 - Expanding clip

- To remove, pull pins out and pry out expanding clips.